



WELCOME TO THE SCOOTI FAMILY



**MANUFACTURERS CONDITIONS OF SALE
(SUBJECT TO WARRANTY CONDITIONS HEREUNDER
AND ATTACHED HERETO)
SERVICE SCHEDULE**

Web: www.scooti.co.za

or

www.SAscooterShop.co.za



ENGINE NO: _____

VIN NO: _____

Agent _____

Date of Purchase _____

Colour _____

Model _____

Registration No _____

Purchaser _____

ID Number _____

Address _____

Telephone Number _____

Cell Number _____

E-Mail _____

Vehicle accepted and delivered in good working order.

I _____ hereby accept all manufacturers conditions of sale, service schedules and warranty conditions and confirm that they were fully explained and discussed with me as per page One (1), Two (2), Three (3), Four (4) and Five (5)

I also confirm that I received a copy of the warranty and owner's manual.
Scooti shall not be held responsible under any circumstance, in the case of: damage, theft, fire, accident, death or injury.

Agent _____

Purchaser _____

Signature Agent _____

Signature Purchaser _____

DEALER STAMP:



Limited Warranty Conditions For Scooti Golf Cruiser

1 Warranty Period. Limited inclusions and specific exclusions as applicable to vehicles incorporating electric motors:

1.1 This warranty is applicable only to the vehicles identified by the VIN and Engine Numbers above ("the vehicle").

1.2 This warranty is dependent upon the regular performance of the maintenance tasks as detailed hereunder.

1.3 The vehicle warranty is valid for 24 months from the date of purchase.

1.4 The battery warranty is valid for 6 months where after it expires.

1.5 The electrical warranty includes only harnesses and electrical modules, wheels (excluding tyres lamps and fuses) and main frame, subject to the conditions herein. All other parts are excluded from the warranty period, the reliability of these items is directly related to the correct maintenance and operation of the unit and will only be repaired under warranty at the sole discretion of the Scooti accredited technical personnel.

1.6 Motor defects and failures attributable to running the vehicle on off-road conditions or through water levels that could cause electric motor failure also void the warranty.

1.7 Any vehicle failures attributable to incorrect use or weight overloading are specifically excluded from the warranty period; the reliability of these items is directly related to the correct operation of the unit.

1.8 The warranty includes only harnesses and electrical modules, subject to the conditions herein. The lamps and fuses are specifically excluded.

1.9 The purchaser has 7 days from date of purchase to report any defects regarding switches, fairings, tyres, and lights. (Offer to purchase must be produced.)

1.10 This warranty is based on a "return to supplier" principle and is limited to a 50km radius from the appropriate store, outside of the 7 day period this is the responsibility of the purchaser.

1.11 Any defect occurring within the 7 day period, which prevents the unit from being operated, must be reported (normal business hours) to the outlet from which it was purchased. Collection and delivery charges for such units will be for Scooti's account.

1.12 Any call out, collection or delivery charges, falling outside of the above will be for the customer's account, irrespective of any repair or warranty work required to return the unit to a serviceable state. Non-disabling defects are to be reported and suitable arrangements made to rectify the defect. Any collection or delivery charges will be for the customer's account.

1.13 The purchaser shall inspect and accept the vehicle when taking delivery. Any surface blemish's or damage is to be brought to the agent's attention immediately. No responsibility for surface damage will be accepted once the unit has departed the premises from which it was obtained. (See Delivery Inspection Document)



2 Limits of Warranty

2.1 This warranty is limited to the replacement of parts, which, in the sole and absolute discretion of an authorized Scooti dealer, are defective and require replacing. Replacement parts required under this warranty will be supplied as soon as possible, but no liability for loss or damage resulting from any delays for whatever reason is accepted and the purchaser shall under no circumstances be entitled to cancel the contract of sale as a result of such delays occurring.

2.2 Scooti reserves the right to:

2.2.1 Make design changes and modifications to vehicles at any time without incurring any obligation to make such design changes and modifications to units previously manufactured and/or sold.

2.2.2 Replace complete assemblies and/or units if the change is, in the opinion of Scooti, so extensive that it would be less expensive to replace the complete assembly and/or unit than to repair it. This is carried out exclusively under the authorization of qualified company personnel. In such cases, the purchaser shall receive only the outstanding portion of the warranty applicable to the original unit.

2.2.3 Adjust those malfunctioning parts which were originally designed to be adjustable, e.g. charger, controller, etc.

2.3 This warranty shall not apply to any Scooti Vehicle:

2.3.1 Whose purchaser has failed/neglected to have the compulsory after-sale services done by an authorized Scooti dealer.

2.3.2 Which was not distributed and sold by an authorized Scooti dealer in South Africa.

2.3.3 Which has been used in racing, speed contests or off road in a manner outside of the vehicles limitations.

2.3.4 Which has undergone a change of ownership during the warranty period, this warranty is not transferable from the original purchaser.

2.3.4 In the case of vehicles that have been used on any surface other than golf courses or tarmac.

2.4 This warrantee excludes any fault and damage, which in the opinion of the dealer is due to fair wear and tear or negligence on the part of the owner.

2.5 This warrantee is only valid if issued and signed by an authorized Scooti dealer on date of purchase.

General Exclusions

3 This warranty does not include:

3.1 Consumable parts including but not limited to fuses, tyres, tyre tubes, brake linings, cables, and rubbers (footrest and handlebar).

3.2 Servicing materials including but not limited to greases, and cleaning materials.

3.3 Maintenance operations including but not limited to brake adjustments, removal and cleaning of deposits from motor, wheel balancing, or damages resulting from misuse or the fitting of non-genuine parts, normal wear and tear, motor adjustments and other items of preventative maintenance.

3.4 Fasteners including studs, clips and split pins, are subject to warrant claim authorization on a case by case basis, and are considered a general exclusion.



4. Specific Exclusions

4.1 The following problems and/or defects are specifically excluded, which in the opinion of Scooti, arose from or are caused by:

4.1.1 The misuse, negligence, abuse or use in any way deviating from the normal use for which the vehicle was designed, including but not limited to accidents howsoever caused, overloading, racing, speed contests or off road usage in a manner outside of the design intensions of the unit.

4.1.2 The incorporation of, or use of, unsuitable attachments, parts or equipment.

4.1.4 Repairs, work or modifications of any nature performed by any person/s that is/are not authorized Scooti dealers or accredited Scooti service centers.

4.1.5 Failure to service the vehicle in accordance with recommended Scooti services routines.

4.1.6 The use of parts other than genuine Scooti parts not specified by Scooti.

4.2 All other defects/problems unrelated to defective parts, including but not limited to noise, vibration, instability, in transit damage, storage damage and corrosion shall likewise be specifically excluded from this warranty.

5 Purchaser's responsibility

5.1 It shall be the responsibility of the purchaser to:

5.1.2 Give notice to an authorized Scooti dealer of any and all defects within seven (7) days after delivery thereof and to thereafter make the Vehicle available for a reasonable period for inspection and repairs at such dealer's place of business. (Offer to purchase must be produced.)

5.1.3 "Return to dealer" transport of the motorcycle after the seven (7) days period, is for the purchasers responsibility and account.

5.2 Failure of the purchaser to comply with the above requirements shall render this warranty null and void.

6 Special Circumstances

6.1 In order to qualify for this warranty, the Scooti vehicle must be registered at the time of purchase and an authorized Scooti dealer must perform the pre-delivery inspection.

6.2 All defective parts replaced under this warranty shall become the property of Scooti.

6.3 The validity of the above warranty is entirely dependent on the user complying strictly with the Scooti manufacturer's conditions of sale as evidenced by completion of the specified servicing record.

6.4 The warranty is only valid as far as the first replacement of any part warranted hereunder, any subsequent replacement of such parts shall be in the sole and absolute discretion of Scooti.

6.5 Scooti has sole right to void the warranty thereof and thereafter if the vehicle was in any accident whatsoever.

6.6 Scooti shall not be held responsible under any circumstance, in the case of: damage, theft, fire, accident, death or injury.



TIPS TO REMEMBER

Maintenance of motor and battery is of great importance for these two parts are the core of the driving system

- The Scooti is specifically designed to drive off road typically golf courses.
- The Scooti is not to drive in very wet conditions or through water.
- Battery must not be left uncharged for long periods of time.
- Your Scooti can be used in the rain but remember to dry the body after a ride.
- Do not touch the two white points at the end of the battery with wet hands.
- Do not try to repair any parts of your Scooti yourself.
- Using light at night will consume battery power and thus reduce driving distance.

CHARGING

- You should recharge the battery after every ride.
- Turn off the ignition switch and remove the key.
- Place the outlet plug of the charger in the charging socket under the seat and then put the inlet plug of the charger in the household electrical socket

Charging time

- When the inlet and outlet plugs of the charger are correctly plugged, the red indicating light of the charger will be on, indicating that the batteries are now being charged
- 8-10 hours later, the green indicating light will show, indicating that the battery is almost fully charged, YOU can continue to charge for a further 1 - 2 hours and unplug the charger.
- The charger has an anti-overload device, long period charging (not over 24 hours) does not influence the lifetime of the battery.

Important aspects regarding charging

- DO NOT use any another charger to charge the batteries.
- DO NOT use the Scooti charger for any other purposes.
- There is a high voltage circuit in the charger, do not take it apart.

To avoid unnecessary damage to the charger, avoid.

- Do not cover the air vent when charging.
- Allow any liquid substance or metal filings near the charger or motor.
- Do not turn your Scooti on whilst charging.
- This charger is suitable for indoor use.
- If the charger or battery is overheated or any abnormal behavior of either is observed during charging, immediately switch the power off at the plug and take the device to the agent for repair.



To ensure your safety before driving check:

- That the batteries are charged.
- Ensure that the tyre pressure is correct.
- That all nuts and bolts are tightly fastened.
- That the brake system is well adjusted

Points to notice about riding

- When taking off, increase the speed slowly, so as to avoid the waste of power to move the weight or the damage of electrical parts.
- Whilst driving do not accelerate whilst braking, this may cause the motor to overload and damage mechanical or electrical parts.
- The controller of this vehicle has an overload protection function, if it is overloading, the power will be automatically cut out, when the loading returns to normal the power will automatically be re-instated.
- Maximum load weight of this vehicle is 150kg [including the weight of the rider, please do not overload.
- This vehicle has a self-check function: when the power indicating light keeps flashing or the vehicle will not power up when using the key, contact the service centre of the company or the distributor for the examination by trained technicians.

How to start the vehicle

- Insert the key into the ignition switch, turn to the ON position and the power indicator light will light up.
- Rotate the right handle bar accelerator , gradually to increase the speed

MAINTENANCE AND REPAIR

- For your safety and the best condition of the vehicle, please maintain and clean the vehicle regularly.
- Lubricate the metal parts; do not get oil on the front brake, rear brake, spokes or tyres.

Regular maintenance and self check

- Tighten all nuts and bolts regularly.
- Check the wear and tear of your tyres.
- Check the pressure of the front and rear tyres.
- Whether the hooter and rear reflector are in working condition.
- If you do not use this vehicle frequently, please do charge the battery regularly (generally speaking once per month) to ensure extended battery life.



Maintenance of battery

The battery used on this vehicle is lead-acid free-maintenance; the lifetime of this battery is closely related to the right way of battery use. Also available is a three year service plan at a fee agreed to by the Scooti Agent in writing to the purchaser.



Delivery Inspection carried out

by: _____ Date: _____

Before delivery your vehicle was inspected according to factory guidelines. This ensures that driving will be a pleasure from the very beginning.

The agent will provide you with the following information:

- Running in
- Service intervals, in particular what constitutes severe operating conditions and nullifies any warranties

SERVICE INSPECTION REPORT

Date of inspection	
Name and surname of service inspector	
Signature of service inspector	

VEHICLE DETAILS

Company:	
Make:	
Model:	
Description:	

A. CONTROLS

All controls that are fitted and required for the operation of the vehicle shall be so located	Yes/No	Remarks
That the rider can operate them when he is seated in a normal riding position		
That they do not impair safe riding		

B. INFORMATION TO BE DISPLAYED

The following information shall be displayed legibly and permanently	Yes/No	Remarks
Engine number on the engine block		
Vehicle Identification Number on the frame		



C. TYRES

Tyre front condition		Tyre rear condition	
Remarks		Remarks	

STEERING GEAR (Reg. 200)

	Yes/No	Remarks
No Play in steering mechanism		
Handlebars Stable		

Brakes and braking equipment (NRTA Reg. 150)

Requirements	Yes/No	Remark
Front Brakes functioning correctly		
Rear Brakes functioning correctly		

Electric Motor

Operational	Non Operational	Remark

Electric Other

Requirements	Operational/Non Operational	Remark
Check Ignition		
Check output wattage		
Check Controller functionality		
Check Accelerator range		
Check Battery Load testing		



--	--	--

Other

Requirements	Operational/Non Operational	Remark
Check all locks		
Torque all required bolts		
Requirements	Yes/No	Remark
Vehicle cleaned and washed		
Check all branding in place		
Check for any scratches or any other defects		

Delivery Inspection agreed to by purchaser

by: _____

: _____

NAME

DATE

.....

.....

SIGNATURE

PLACE

.....



REGION

The importance of the service schedule

The service schedule confirms the date of delivery of your vehicle and thus the beginning of its warranty cover

The vehicle data given in your service warranty will ensure that you will always be able to have the correct Scooti genuine parts installed in your vehicle. This data helps ensure that any warranties that are agreed when purchasing a new Scooti are honored.

First Service 100 Hours

Date		Dealer Stamp
Job card Number		
Kilometers		
Signature		

Second Service 300 Hours

Date		Dealer Stamp
Job card Number		
Kilometers		
Signature		



Third Service 500 Hours

Date		Dealer Stamp
Job card Number		
Kilometers		
Signature		

Fourth Service 800 Hours

Date		Dealer Stamp
Job card Number		
Kilometers		
Signature		

Fifth Service 1000 Hours

Date		Dealer Stamp
Job card Number		
Kilometers		
Signature		



--	--	--